### Customizable features

Your vehicle includes a variety of electronic features that can be personalized to suit your preferences. Programming these preferences requires specialized equipment and may be performed by your Lexus dealer.

It is also possible to customize certain vehicle features yourself using the multi-information switches and the navigation screen.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

### Customizing vehicle features

It is possible to customize certain vehicle features using the multi-information switches.\*

When customizing vehicle features, ensure that the vehicle is parked in a safe place with the shift lever in P and the parking brake set.



Press and hold the menu switch of the multi-information switches to display customization mode.



Press the "ENTER" switch upwards or downwards to select the item to be customized and press the "ENTER" switch to confirm



Press the "ENTER" switch upwards or downwards to select the desired setting for the item being customized and press the "ENTER" switch to confirm.

When customization is completed, press the menu switch to clear the customization screen.

\*: For instructions on customizing vehicle features using the navigation screen, refer to the "Navigation System Owner's Manual".

### Customizable Features

- Vehicles with a navigation system: Settings that can be changed using the screen of the navigation system
- Vehicles with a navigation system: Settings that can be changed using the multi-information switches
- Sehicles without a navigation system: Settings that can be changed using the multi-information switches
- ☑ Settings that can be changed by your Lexus dealer Definition of symbols: O = Available, = Not available

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
	Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step	0	_	_	0
Door lock (→P. 57, 533)	Speed-detect- ing automatic door lock func- tion	Off	On	0	-	0	0
	Selecting other than P position locks all doors	On	Off	0	_	0	0
	Pressing the P position switch unlocks all doors	On	Off	0	-	0	0

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
Door lock (→P. 57, 533)	Opening driver's door unlocks all doors	Off	On	0	_	0	0
Smart	Operation signal (Emergency flashers)	On	Off	0	-	0	0
access sys- tem with	Open door warning buzzer	On	Off	_	_	_	0
push-button start and	Operation signal (buzzer volume)	Level 7	OFF to level 6	0	-	0	0
wireless remote con-	Time elapsed		Off				
trol (→P. 44,	before the auto- matic door lock function is acti-	60 sec-	30 sec- onds	0	_	0	0
54)	vated if a door is not opened after being unlocked	onds	120 sec- onds				
C 1	Smart door unlocking	Driver's door	All the doors	0	-	0	0
Smart access sys- tem with push-button start	Smart access system with push-button start	On	Off	0	-	0	0
(→P. 44)	Number of consecutive door lock operations	2 times	As many as desired	_	-	_	0

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
	Wireless remote control	On	Off	-	-	-	0
Wireless remote con-	Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step	0	-	0	0
trol (→P. 54)	Panic function	On	Off	-	_	-	0
	Trunk unlocking operation	Press and hold (short)	One short press	-	-	-	0
			Press twice	-	_	-	0
			Press and hold (long)	-	-	_	0
			Off	-	_	-	0
			Off				
Automatic light control	Time elapsed before the head-	30 sec- onds	60 sec- onds	0	_	0	0
system $(\rightarrow P.183)$	lights turn off		90 sec- onds				
	Light sensor sensitivity	Standard	-2 to 2	0	-	0	0
Lights (→P. 183)	Daytime run- ning light system	On	Off*	0	-	0	0

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
			Off				
	Time elapsed before the inte-	15 seconds	7.5 sec- onds	0	_	0	0
	rior lights turn off		30 sec- onds				
	Operation after the "POWER" switch is turned off	On	Off	-	-	-	0
Illumination (→P. 360)	Operation when the doors are unlocked	On	Off	_	_	_	0
	Activate on approach of per- son carrying smart key	On	Off	-	_	-	0
			Off				
	Time elapsed before the exte-	15 seconds	7.5 sec- onds	0	-	0	0
	rior lights turn off		30 sec- onds				
	Footwell lighting	On	Off	-	-	-	0

<sup>\*:</sup> Vehicles sold outside Canada

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
	Outer foot lights activate on approach of per- son carrying smart key	On	Off	-	_	_	0
Illumination (→P. 360)	Outer foot lights operation when the doors are unlocked	On	Off	-	-	_	0
	Remote touch light	On	Off	_	_	_	0
Meter	Sensitivity of the ambient light sensor used for dimming the meter lights etc.	Standard	-2 to 2	0	_	_	0
(→P.162)	Sensitivity of the ambient light sensor used for brightening the meter lights etc.	Standard	-2 to 2	0	-	_	0
Automatic air conditioning system (→P. 252)	Switching between outside air and recircu- lated air mode linked to "AUTO" switch operation	Auto	Manual	0	_	_	0

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
Automatic	A/C Auto switch operation	Auto	Manual	0	-	_	0
tioning system (→P. 252)	Turning on the windshield defogger activates the A/C	On	Off	-	_	-	0
Front seats	Driver's seat movement when exiting the vehicle (on some models)  Off Partial Full	movement when	Off	0	_	0	0
(→P. 64)		Full					
Multi-infor- mation dis- play (→P. 169)	Eco Driving Indi- cator Light	On	Off	-	0	0	-
	Mechanical key linked operation	Off	On	-	-	-	0
Power windows (→P. 86)	Wireless remote control linked operation	Off	On (Open only)	_	-	_	0
	Buzzer sounds if operated using wireless remote	On	Off	_	-	_	0

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
	Mechanical key linked opera- tion*	On	Off	_	_	_	0
Moon roof	Linked operation of components when door key is used	Slide only	Tilt only	-	-	-	0
(→P. 89)	\ <i>\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\</i>	On (Open only)	Off	-	_	_	0
	Linked operation of components when wireless remote control used	Slide only	Tilt only	_	_	_	0
			Off	-	_	-	0
	Time elapsed before the		0 seconds	_	_	_	0
Rear sun- shade	reverse opera- tion feature acti-	0.7 sec- onds	0.9 sec- onds	-	-	-	0
(→P. 378)	vates		1.2 sec- onds	-	-	_	0
	Reverse operation	On	Off	-	-	-	0

<sup>\*:</sup> This function cannot be customized unless power window operation using the wireless remote control or mechanical key is enabled.

ltem	Function	Default setting	Custom- ized setting	1	2	3	4
Driving position memory (Driver's seat) (→P. 68)	Called up when door is opened with smart access system with push-but- ton start	Driver's door	All doors	-	_	-	0
	Signal (buzzer) when the distance to obstacles does not change for 3 seconds or more	On	Off	-	_	_	0
Intuitive parking assist*	Signal (buzzer) when the shift position is changed to N	Off	On	-	-	_	0
	Active sensors when the shift position is out of P or R	Front corners	Rear centers, Rear corners	-	_	_	0
Seat belt reminder (→P. 495)	Vehicle speed linked seat belt reminder buzzer	On	Off	_	-	-	0
Reverse buzzer (→P. 159)	Signal (buzzer) when the shift position is in R	Intermit- tent	Single	-	-	-	0

<sup>\*:</sup> Refer to "Navigation System Owner's Manual"

# Multi-information display ( $\rightarrow$ P. 169)

Settings that can be changed using the multi-information switches

Available units	miles (MPG), km (km/l), km (l/100 km)
Available languages	English, French and Spanish

#### n Vehicle customization

- 1 When the "Speed-detecting automatic door lock function" and "Selecting other than P position locks all doors" are both on, the door lock operates as follows.
  - When shifting the shift lever to any position other than P, all the doors will be locked.
  - If the vehicle is started with all the doors locked, the "Speed-detecting automatic door lock function" would not operate.
  - If the vehicle is started with any door unlocked, the "Speed-detecting automatic door lock function" will operate.
- 1 When the smart access system with push-button start is off, the "Smart door unlocking function" cannot be customized.
- 1 When the doors remain closed after unlocking the doors and the "Automatic door lock function" activates, the signals will be generated in accordance with the "Operation signal (emergency flashers)" and the "Operation signal (buzzer volume)" settings.
- n In the following situations, customize mode in which the settings can be changed through the multi-information switches will automatically be turned off.
  - 1 A warning message appears after the customize mode screen is displayed.
  - 1 The "POWER" switch is turned off.
  - 1 The vehicle begins to move while the customize mode screen is displayed.



# **A** CAUTION

### n Cautions during customization

As the hybrid system needs to be running during customization, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.



# NOTICE

### n During customization

To prevent 12-volt battery discharge, ensure that the hybrid system is running while customizing features.